

Dewalt 744 Table Saw Manual



File Name: Dewalt 744 Table Saw Manual.pdf

Size: 3016 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 21 May 2019, 16:11 PM

Rating: 4.6/5 from 641 votes.

Status: AVAILABLE

Last checked: 8 Minutes ago!

In order to read or download Dewalt 744 Table Saw Manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Dewalt 744 Table Saw Manual . To get started finding Dewalt 744 Table Saw Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Dewalt 744 Table Saw Manual

Sierra de banco para el lugar de trabajo de 254 mm 10 pulg. de alta resistencia Whenever the adapter DO NOT use a sheet metal screw. Definitions Safety Guidelines Electric Code. WARNING Read all instructions before operating product. Failure to follow all. Double Insulation. If saw is of double insulated construction, read the following instructions. This symbol Double insulated tools are Tools built with this As a result, your tool is equipped with a NOTE Double insulation does not take the place of normal safety precautions when Grounding Instructions. If saw is of grounded construction, read the following instructions. This machine is equipped with Do not modify the plug provided if it The conductor with insulation having an outer surface that is green with or without If repair or replacement of the This plug will fit in a polarized outlet If it still does not fit, contact a qualified electrician to install the proper Important Safety Instructions Form habit of checking to see that Cluttered areas and benches invite accidents. The use of power All visitors should be kept at a safe distance from work area. Your shop is a potentially dangerous environment. B, may be used to connect this plug to a matching two conductor receptacle as shown The temporary adapter should be The definitions below describe the level of severity for each signal word. Please read DANGER Indicates an imminently hazardous situation which, if not avoided, WARNING Indicates a potentially hazardous situation which, if not avoided, CAUTION Indicates a potentially hazardous situation which, if not avoided, may NOTICE Indicates a practice not related to personal injury which, if not avoided, English. Serious injury could occur if the tool is tipped or if the cutting Before further use of the tool, a guard or other part Damaged parts can cause TURN POWER OFF. Don't leave Serious injury can result. <http://bbox.ru/images/shared/boss-770-drum-machine-manual.xml>

- **dewalt 744 table saw manual, dewalt 744 table saw parts, dewalt dw744 table saw specs, dewalt 744 table saw owners manual, dewalt 744 table saw manual, dewalt 744 table saw manual, dewalt 744 table saw manual instructions, dewalt 744 table saw manual download, dewalt 744 table saw manual 2017, dewalt 744 table saw manual 2016, dewalt 744 table saw manual parts, dewalt 744 table saw manual review, dewalt 744 table saw manual for sale, dewalt 744 table saw manual diagram, dewalt 744 table saw manual.**

Make sure your extension cord is in good When using an extension cord, be sure to use one heavy enough An undersized cord will cause a drop in line The following table shows the correct If in doubt, use the More Not more WEAR PROPER APPAREL. No loose clothing, gloves, neckties, rings, bracelets, or Non slip footwear is recommended. Wear Air vents may cover moving parts and Also use face or dust mask if cutting operation is dusty. All users and bystanders. MUST ALWAYS wear certified safety equipment. DO NOT OVERREACH. Keep proper footing and balance at all times. Loss of balance Do not touch the plug's An accidental startup can cause In the event of a power failure, An accidental startup can cause injury. Accessories that may be suitable for one tool Consult the instruction manual for The use of improper accessories may cause risk of injury Additional Safety Rules for Table Saws All users and bystanders. WARNING Do not expose to rain or use in damp locations. Instructions for making a WARNING Never perform freehand cutting with this saw. WARNING Never perform plunge cutting with this saw. The riving knife is a flat plate that fits into the cut made by the saw blade and effectively The blade guard Use all components of the guarding system blade guard assembly, riving knife and antikickback assembly for every operation for which they can be used including all through Replace the guarding Keep the guard assembly MAKING A PUSH STICK Inside Back Cover A push stick is included with this saw. It's a good

idea to have several push sticksThe shape can vary to suit yourA kickback occurs when a part of theKickbacks can be avoided by attention toHow to Avoid Them and Protect Yourself from Possible InjuryFeed force when ripping should always be applied between the antikickback assembly is not operational, return your unitCertain manmadeFollow the manufacturer'sDamage to the saw and personal injury may result.Always tighten the blade arbor nut securely.<http://arch-harmony.com/upload/20200828159860641859.xml>

Before use, inspect the blade for cracks or missing teeth. Do not use a damaged or dullA sudden slip could cause a hand to move into the blade. Severe injury can result.Hold the work firmly against the fence and down against theContact a DEWALT factory service center, a DEWALT authorizedStand to the side whenever possible. The use of improper accessories may causeA machine incorrectly assembled can cause serious injury.Knowledge is safety.Cleveland, OH 441152851
www.powertoolinstitute.com. Information is also availablePlease refer to the U.S. Department of Labor OSHA 1910.213 Regulations. English. UnpackingThe riving knife must beThe teeth must prevent the wood from being pulled toward theWARNING Some dust created by power sanding, sawing, grinding, drilling, and otherSome examples of these chemicals are. Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals work in a wellventilated area, and work withWear protective clothing and wash exposedAllowing dust to get into your mouth, eyes or lay on theDirect particles away from faceUse dust collection system wherever possible. WARNING To reduce the risk ofOpen the box and slide the sawCarefully unpack the table sawIf any parts are missing orFigure 2 shows all the loose itemsWARNING To reduce the risk of serious personal injury, have push stick ready to useAmperes. Table Size. Miter Angle. Bevel Angle. Blade Size. Max. Cut Depth. RPM, no loadThe followingN. Blade guard lock lever. O. Riving knife. P. Antikickback assembly. Q. Dust collection portArbor wrench, spindle wrench. Work Support Extension retracted. Push stickSee Adjusting Rip Scale.Tools needed for assembly include the wrenches included with your saw.To reduce the risk of serious personal injury, turn unitAn accidental startup can cause injury.Circuit breaker button. Mounting holes. Miter gauge. Screw down holesB. Blade. C. Rip scale indicator. D. Fine adjust knob. E. Rail lock lever.

F. Blade height adjustment wheel. FEATURES Fig. 3, 4Ensure the spindle and washers areTherefore, it isReplacement blade. MUST not exceed the thickness stated on the riving knife. The riving knife provided withWARNING Before connecting the table saw to the power source or operating theCheck alignment after each change of bevel angle. NOTE DO NOT operate saw if riving knife is not locked in the thru-cut ZZ or non thru-cutWhen properly aligned, the riving knife will be in line with the blade at both table top level,Using a straight edge, ensure that the blade B is aligned withWith power disconnected, operate the blade tiltWhen properly adjusted, the front of theWARNING To reduce the risk of serious personal injury, the throat plate must be lockedSee StorageDepress the stem AA on the anti kickback assembly toPush down on the antikickback assembly untilNOTE Pull up on the antikickback assemblyRetighten the ripThe rip scale reads correctly onlyBench Mounting Fig. 3. WARNING To reduce the risk of serious personal injury, turn unit off andAn accidental startup can cause injury. CAUTION To reduce the risk of personal injury, make sure table saw is firmly mountedCAUTION Ensure that the surface is stable enough that large pieces of material will notThe table saw must be mounted firmly.Four holes J are provided in the tool's feet for mounting. We strongly recommend thatThe DEWALT DW7440 Table Saw. Stand and the DW7440RS Rolling Stand are designed for use with the DW744. They areThese strips canSee Figure 13.Rotate until the blade guardSee Figure 14.Check to make sureIf the guardSee Figure 15. Connecting Saw to Power Source. WARNING To reduce the risk of injury, before connecting saw to power source, makeBe sure your power supply agrees with the nameplate marking. AC ONLY means that yourA voltage decrease of 10 percent or more willAll DEWALT tools are factory tested.

<https://ayurvedia.ch/4-speed-manual-transmission-shift-pattern>

If this tool does Rip Fence Operation NOTE When ripping, always lock the rail WARNING To reduce the risk of injury, be sure Lift the switch paddle I up to turn your saw ON and A hole JJ is provided in the switch for insertion of a Figure 18. NOTE Retract the work support extension whenever working over the table. WARNING To reduce the risk of injury, turn unit NOTE Your saw is fully and accurately adjusted at the factory at the time of manufacture. If Once made, these adjustments should remain accurate. Take a little time now to follow Adjust this nut until the See Adjusting the. Rip Scale under Assembly. Scale under Assembly. WARNING Cut Hazard. Check the blade at 0 and 45 to make sure blade does not hit If the blade appears to be out of alignment with the miter slot on the table top, it will To realign the blade and miter slot, use the following WARNING To reduce the risk of injury, turn unit off and disconnect machine from An accidental startup can cause injury. Using a 10 mm socket, loosen rear pivot bracket If you experience fence alignment problems and want to Make sure you measure See To Remove Throat Plate See Positioning Riving Knife These screws will be used to If the pointer does not read The riving knife should not touch the straight edge. If English. Saw Blades. WARNING Riving knives must be matched to saw blade Knife Selection. The riving knife thickness MUST be replaced with one that has the correct thickness. If a different blade is used and the body thickness and CAUTION Abrasive wheels or blades including The riving knife provided with this saw is marked as DEWALT is marked as follows Kickback. Kickback is a dangerous condition.

<http://erka-techserv.com/images/Cydia-Fix-It-Manually.pdf>

It is caused by the The result is that the It can also drag the operator's WARNING See Additional Safety Rules for Table Saws WARNING To minimize the risk of kickback and to The riving knife supplied with this table saw is the correct WARNING To reduce the risk of injury, turn unit off An accidental ALWAYS make sure both guards are in the down WARNING Never touch the "free end" of the workpiece Piece may contact the blade WARNING A rip fence should ALWAYS be used for ALWAYS lock the fence to the rail. WARNING When bevel ripping and whenever possible, WARNING Keep hands clear of the blade. WARNING Use a push stick to feed the workpiece if Remove the miter gauge. Failure to adhere to these common safety rules can greatly WARNING To reduce the risk of injury, turn unit off An accidental WARNING Before connecting the table saw to the Personal injury WARNING Ripping or crosscutting may cause saw to tip Make sure saw is securely mounted WARNING Never use the fence and miter gauge CAUTION If your saw makes an unfamiliar noise or if Contact a DEWALT factory CAUTION The proper throat plate must be in place at all There are two basic types of cutting with table saws Cutting with the grain is ripping WARNING When ripping, always use the fence to WARNING Never perform any cutting operation free CAUTION When crosscutting, always use the miter CAUTION The workpiece must have a straight edge against Both hands can be used in starting the cut. When there Always keep The work support must be at the same height as the saw CAUTION Never push or hold onto the "free" or "cut off" Ripping Small Pieces. It is unsafe to rip small pieces. It is not safe to put your hands A pattern is included A push stick Figure 33. English Bevel Ripping. IMPORTANT Only use the push block A12 with the The push block should be used once the material being cut NOTE Edges A15 must be the same size. IMPORTANT The over hanging edge A16, Fig. 35. MUST be square.

<http://lamda-maritime.com/images/Cyclosizer-Operating-Manual.pdf>

An uneven lip could cause the push This operation is the same as ripping except the bevel angle WARNING Before connecting the table saw to the power Check alignment after each Narrow Rip Auxiliary Fence NOTE A11 should be cut to fit IMPORTANT The narrow rip auxiliary fence and the over Crosscutting. WARNING NEVER touch the "free end" of the workpiece Piece may contact the WARNING To reduce the risk of injury, NEVER use the WARNING NEVER use a length stop on the free end In short, the cutoff WARNING Use caution when starting the cut to prevent CAUTION

When using a block as a cutoff gauge, keep the workpiece an inch or so in front of the blade. Turn the switch off, allow the blade to cool. CAUTION Never touch or hold onto the "free" or "cut off" end of the workpiece. Miter Gauge Operation. To set your miter gauge, loosen the lock handle and move the miter gauge to the desired angle. This is a combination of bevel crosscutting and mitering. Follow the instructions for both bevel and crosscutting. Bevel Crosscutting. When installing the dado stack, do not replace it with the outer clamp washer, then install the dado stack. Since dado cuts are not through cuts, the cuts must be performed with the blade. To remove the blade guard assembly, lift guard lock lever. When using the dado, the special dado insert also sold as an accessory must be used. Anytime a cut is required that is considerably wider than the saw kerf, a dado is used. Use EXTREME care when using the dado without the blade guard assembly and use several successive passes rather than attempting one large cut. Be sure to place the blade guard assembly and standard throat plate back in position. Reinstall blade guard. This operation is the same as crosscutting except that the bevel angle is set to an angle. Check alignment after each change of bevel angle. Mitering. WARNING Miter angles greater than 45.

CAUTION Certain workpiece shapes, such as molding may not lift the blade guard. If the blade guard assembly is not lifted, the blade guard may damage the workpiece. This operation is the same as crosscutting except the miter gauge is locked at an angle. Featherboard Construction. Featherboards are used to keep the work in contact with the fence and table, and help prevent work from shifting. Make the featherboard from a straight piece of wood that is free of knots and cracks. Clamp featherboard to the table. Always replace the featherboard when it becomes damaged. English. Compound Mitering. Make sure the featherboard presses only on the portion of the workpiece being cut. An accidental startup can cause injury. English. WARNING Blowing dust and chips out of the motor housing using clean, dry air. Dust and chips containing dust. Many household dusts are irritants. Also, do not use compressed air to clean your face or clothing. Never let any liquid get inside the tool; never immerse the tool in liquid. Lubrication. Dust Collection. Your table saw is equipped with a dust collection system. After extended use, the saw's dust collection system may become clogged. To clear the dust collection system, use compressed air. Recommended accessories for use with your tool are available at extra cost from your local retailer. If you need assistance in locating any accessory, please call 1-800-4-A-DEWALT. WARNING If power is interrupted by a circuit breaker trip, make sure the switch is in the OFF position before restoring power to prevent the saw from starting unexpectedly. Circuit breaker overload is often the result of a dull blade. Change your blade on a regular basis. Check your blade before resetting the circuit breaker. To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment always use identical replacement parts. See the instruction manual for details. To Remove Blade guard assembly. Slide blade guard while depressing stem. Place the riving knife. Three Year Limited Warranty. DEWALT will repair, without charge, any defects due to faulty materials or workmanship. This warranty does not cover part failure due to misuse. For further detail of warranty coverage and warranty repair, visit www.dewalt.com. In addition to the warranty, DEWALT tools are covered by our 3-Year Limited Warranty. LATIN AMERICA This warranty does not apply to products sold in Latin America. For more information, visit www.dewalt.com. FREE WARNING LABEL REPLACEMENT If your warning labels Fig. 46 become illegible, visit www.dewalt.com for more information. Push Stick Pattern.

Adjust length of push stick so hand will clear blade guard and rip fence. Ajuste el largo de las varas de empuje para que la mano se resbale. CAUTION Make push stick from plywood or particle board. Optional hanging hole. Trou de suspension optionnel. Orificio para colgar opcional. Notch to help prevent hand from slipping. Muesca para prevenir que la mano se resbale. DEWALT Industrial Tool Co., 701 Joppa Road, Baltimore, MD 21286. Page Count 35 YOUR FEEDBACK IS VITAL TO THE SUCCESS OF DEWALT'S QUALITY IMPROVEMENT PROGRAM. See Scies circulaires. Sierra de banco. World. Wide. Web. Each tool is produced with painstaking care. WARNING When using electric tools, basic safety precautions should always be followed. Double insulated tools are constructed throughout with two separate layers of electrical insulation or one double thickness of insulation between you and the tools electrical system. Tools built with this insulation system are not intended to be grounded. As a result, your tool is not grounded. NOTE Double insulation does not take the place of normal safety precautions when operating this tool. The insulation system is for added protection against injury resulting from a possible electrical insulation failure within the tool. CAUTION WHEN SERVICING USE ONLY

IDENTICAL REPLACEMENT PARTS. Repair Polarized. Plugs If the plug does not fit fully If it still does not fit, contact a qualified electrician to install the Important KEEP GUARDS IN PLACE and in working order. Keep work area well lighted. KEEP CHILDREN A WAY. All visitors should be kept safe distance from work area. MAKE WORKSHOP KID PROOF with padlocks, master switches, or by removing starter DONT FORCE TOOL. It will do the job better and safer at the rate for which it was designed. USE RIGHT TOOL. Dont force tool or attachment to do a job for which it was not designed. When using an extension cord, be sure to use one heavy enough to carry the current your The following table shows the correct size to use depending on cord If in doubt, use the next heavier gage.

The smaller the Minimum Gage for Cord Sets. Volts More. Not more. Than. Than WEAR PROPER APPAREL. Do not wear loose clothing, gloves, neckties, rings, bracelets, IV on slip footwear is recommended. Wear protective hair covering to contain long hair. Air vents often cover moving parts and Safety Saw Everyday eyeglasses only have impact resistant lenses, they are not safety glasses. SECURE WORK. Use clamps or a vise to hold work when practical Its safer than using DONT OVERREACH. Keep proper footing and balance at all times. DISCONNECT TOOLS before servicing; when changing accessories, such as blades, bits, NEVER STAND ON TOOL. Serious injury could occur ff the tool is tipped or ff the cutting tool CHECK DAMAGED PARTS. Before further use of the tool, a guard or other part that is A guard or other DIRECTION OF FEED. Feed work into a blade or cutter against the direction of rotation of REPLACEMENT PARTS. When servicing, use only identical replacement parts. KEEP GUARDS in place and in working order. STABILITY. Make sure table saw is firmly mounted before use. AVOID awkward hand positions, where a sudden slip could cause a hand to move into a Never reach in back of, or around, the cutting tool with SHUT OFF the saw and disconnect the power cord when removing the table insert, changing the cutting tool, removing or replacing the blade guard, or making adjustments. ALWAYS maintain control of the workpiece. DO NOT let go of the workpiece until it is well WHEN REMOVING short workpieces, or cleaning up around the table, be sure the saw is NEVER turn the saw ON before clearing the table of all tools, wood scraps, etc., except WHEN changing saw location, disconnect power. USE extra caution when the guard assembly is removed for resawing, dadoing, rabbeting, If ripping at the time, check Readjust as indicated.

Adjust fence ff not parallel Keep teeth sharp, ff The teeth must prevent the NEVER use a length stop on the free end of the workpiece IF YOUR SAW makes an unfamiliar noise or ff it vibrates KEEP OUT of the fine of saw blade. Stand to the side USE a pushstick when required. See page 9. PAY particular attention to instructions on reducing risk of NEVER reach around, behind or over saw blade. Some examples of these chemicals are Your risk from these exposures varies, depending on how To reduce your exposure to Wear protective Allowing dust to Direct particles away from face and body. Under some conditions and duration of use, noise Table Size. RPM, no load Open the box and slide the saw out, as shown in Figure 1. Carefully unpack the table saw and all loose items from the If any parts are missing or Figure 2 shows all the loose items and hardware packed with Assembly The rip fence can be installed on the left or right side of your Figure 5. Align the pin with the slot and align the latch Assemble the washers and arbor nut to the spindle and Ensure the spindle and Retighten the The rip scale reads correctly Figure 10. Make sure that there If the splitter is tilted relative Check alignment after each change of bevel angle. When properly aligned, the splitter will be in line with the Check using the straight edge. With power disconnected, When properly adjusted, The rear of the throat plate should be flush or slightly Bench. Mounting The mounting sup Four holes are provided in the tools feet for mounting. We Alternately, to enhance the saws portability, it can be. DEWALT DW7440 Table Saw Stand is designed for use with CAUTION Make sure table saw is firmly mounted before Connecting Source. IMPORTANT Before connecting saw to power source, Be sure your power supply agrees with the nameplate marking. AC ONLY means that your saw will operate on alternating current only. A voltage decrease of 10 percent or more All DeWalt tools Operation To lock

the rail lock lever, push it down.

To unlock the lever, pull it up see Figure 9. NOTE When ripping, always lock the rail lock lever. When not in use, the work support extension retracts, as NOTE Retract the work support extension whenever working over the table. Before adjusting, be Lift the switch paddle up to turn your saw ON and push it A hole is provided in the switch for insertion of a padlock to Adjustments. NOTE Your saw is fully and accurately adjusted at the factory at the time of manufacture. If readjustment due to shipping and handling or any other reason is required, follow the Once made, these adjustments should remain accurate. Take a little time now to follow these directions carefully to RAIL LOCK ADJUSTMENT Figure 18. Adjust this nut until the gap between the Using a 10mm Tighten the bevel stop screw. If the pointer does not read Retighten the pointer screw. NOTE If there is not enough travel in the pinion bearing Loosen the screw Saw It is recommended that you locate a reputable sharpening service Kickback is a dangerous condition. It is caused by the workpiece binding against the blade. The result is that the workpiece can move rapidly in a direction opposite to the feed It can also drag the operators hand Use extra caution The workpiece must have one straight, smooth side to go against The workpiece must sit flat Allowing them to Operation The following methods feature safety. As with all power tools Through sawing is any operation which renders the material into two separate pieces. Observe the safety rules included in this manual. Instructions. There are two basic types of cuts ripping and crosscutting. In general, cutting with the grain is ripping and across the However, with man made materials Therefore, cutting a piece of wood to a different width is ripping and cutting across the short dimension is crosscutting. Neither ripping or crosscutting may be done safely freehand! Ripping Small Pieces It is unsafe to rip small pieces.

It is not safe to put your hands A pattern is included on Use them to hold the workpiece Failure Crosscutting. Ripping Remove the miter gauge. When there is approximately Always keep your thumb along Turn the switch off, allow the blade to stop, raise the Bevel This operation is the same as ripping except the bevel angle Check alignment after each change of bevel angle. Keep the workpiece an inch or so in front of the blade. Turn the switch off, allow the blade to stop, and carefully Bevel This operation is the same as crosscutting except that the Check alignment after each change of bevel angle. This operation is the same as crosscutting except the To set your miter gauge, loosen the lock handle and move The miter gauge has. To rotate the miter Compound. This is a combination of bevel crosscutting and mitering. Follow the instruction for both bevel crosscutting and Cutting. A CAUTION Do not attempt to stack dado blades thicker Replace it with the outer Since dado cuts are not through cuts, the cuts must be performed with the blade guard removed. To remove the blade When using the dado, the special dado insert also sold as Anytime a cut is required that is considerably wider than the A dado cut is commonly used to Use several successive Maximum Be sure to place the guard and standard throat plate back in Dust. Collection. Your table saw is equipped with a dust shroud and dust collection port. For best results, connect a vacuum to the port If the saw is operated without a vacuum attached, most off If the saw is used on a After extended use, the saws dust collection system may Clean out the When cutting wet wood without a vacuum or when cutting Lubrication. If you need assistance in locating any accessory, please Baltimore, MD 21286 or call 18004 DEWALT 18004339258. Cleaning. Use only mild soap and damp cloth to clean the tool. Never let Important. To assure product SAFETY and RELIABILITY, repairs, Three. Year. Limited. Warranty.

DEWALT will repair, without charge, any defects due to For further detail of warranty coverage and warranty repair information, visit This warranty does not apply to accessories or damage caused where repairs have been made or attempted by In addition to the warranty, DEWALT tools are covered by If you have difficulty raising or Accessories. Recommended accessories for use with your tool are available at extra cost from your distributor or local service center. DEWALT manufactures

the following accessories for your Portable Saw Stand. Outfeed Side Support. Replacement Throat Plate. Dado Throat Plate
FREE WARNING LABEL REPLACEMENT If your warning label is missing, please contact your retailer. Chacun deux est soigneusement vérifié avant de quitter l'usine afin de s'assurer que l'outil répond à la norme. Ne jamais exiger d'un petit outil ou d'un accessoire le NE PAS DÉPASSER SA PORTEE. Toujours demeurer dans une position stable et garder l'outil en position hors tension avant de brancher l'outil. Le chiffre indiquant le calibre est inversement proportionnel au calibre du calibre minimal des cordons de rallonge. Tension. Longueur totale du cordon en pieds. De 51 à 100. Ne jamais placer l'outil de coupe. Lors du remontage, ne pas laisser l'habitude acquise. Toujours se rappeler de bien soutenir la tension ou que la lame tourne. Autrement dit, il ne faut pas utiliser l'arsenic et le chrome dans le bois de sciage ayant une mise en garde. Porter un dispositif de protection. Puissance HP. Dimensions de la table. Angle des onglets. Angle des biseaux. Dimension de la lame. Prof. de coupe max. Prof. de coupe max. Examiner les figures 3 et 4 afin de mieux connaître la scie. Montage II faut un tournevis et les clés fournies pour procéder à l'installation de la lame en faisant tourner dans le sens horaire la manivelle de réglage de la scie. Installer les rondelles et le crou de l'axe sur l'arbre. Resserrer les écrous de la scie. Le bord du couteau séparateur de la scie et la lame. Retirer le protecteur de la lame.

Serrer solide IMPORTANT LE PROTECTEUR DE LA LAME DOIT ÊTRE ENCLAVÉ Lorsque l'alignement est correct, le réglage de la hauteur de la lame est correct. Lorsque la scie est débranchée, faire fonctionner le dispositif de réglage de la hauteur de la lame. Montage Les pieds de l'outil sont pourvus de quatre trous pour la solution de Workmate md afin de faciliter le transport. Le support de la pièce doit être bien serré. Lorsque vous voulez vous servir de la scie, l'interrupteur est en position HORS TENSION. Une baisse de tension de plus de 10 p. 100 entraîne une perte de puissance. Tous les outils DeWALT sont essayés. NOTE Toujours bloquer le levier de verrouillage des rails avant de procéder lorsque vous installez une lame d'une épaisseur différente. Interrupteur. Soulever la palette de l'interrupteur pour mettre la scie en position. L'interrupteur comporte un trou afin de pouvoir y insérer un tournevis. Avertissement S'assurer que l'interrupteur est en position hors tension lorsque ces réglages sont effectués, ils sont permanents. Prendre le temps de suivre soigneusement les consignes de sécurité. File Type Extension pdf. PDF Version 1.2. Linearized No. Page Count 35. Page Layout Single Page. Page Mode Use None. Producer Goby Monitor Application version 3, 2, 1, 4. Create Date Sat Mar 29 11:39:36 2014. Author. Title. Subject. Please check your inbox, and if you can't find it, check your spam folder to make sure it didn't end up there. Please also check your spam folder. Each tool is produced with painstaking precision using advanced manufacturing systems and intense quality control. Every tool is checked before it leaves the factory to make sure that it meets your standards for durability, reliability and power. Tools built with this insulation system are not intended to be grounded. As a result, your tool is equipped with a two prong plug which permits you to use extension cords without concern for maintaining a ground connection. The insulation system is for added protection against injury resulting from a possible electrical insulation failure within the tool.

<http://www.raumboerse-luzern.ch/mieten/4-speed-manual-transmission-shift-pattern>